Precision Cooling For Business-Critical Continuity

Liebert Deluxe System/3[™] - Chilled Water

Installation Manual - 50 and 60 Hz, 2-60 Ton CW Systems (FH/UH)







TABLE OF CONTENTS

Prod	ист Мос	DEL INFORMATION
EQUIF	MENT IN	SPECTION
1.0	INTROD	UCTION
1.1	System	Descriptions
	1.1.1 (Chilled Water Systems
2.0	INSTALL	ATION
2.1	Room P	reparation
2.2	Location	n Considerations
2.3	Unit Di	mensions
2.4	Piping	
		Drain Line 10 Piping Considerations for Raised-Floor Applications 10
2.5	Electric	al Connections
2.6	Air Dist	tribution Considerations
	2.6.2 1 2.6.3 1 2.6.4 1	Raised-Floor Air Flow Distribution Considerations18Upflow Systems Installation Considerations19Ducted Application Installation19Plenum Installation19Filter Box Installation (Upflow Rear Return)19
3.0	CHILLEI	D WATER MODELS
3.1	Piping (Considerations

FIGURES

Figure 1	Downflow chilled water (FH models except FH599C/FH600C and FH739C/FH740C) cabinet	
i iguio i	and floor planning dimensional data	4
Figure 2	Downflow chilled water models FH599C/FH600C and FH739C/FH740C cabinet and floor planning dimensional data	6
Figure 3	Upflow chilled water (UH models) cabinet and floor planning dimensional data	$\overline{7}$
Figure 4	Cabinet and floor planning dimensional data (UH 599C, 600C, 739C and 740C chilled water models)	8
Figure 5	Blower duct and deck dimensional data (UH 599C, 600C, 739C and 740C chilled water models)	9
Figure 6	Electrical connection details.	11
Figure 7	Electrical field connections for downflow chilled water models (except FH599C/FH600C and FH739C/FH740C)	12
Figure 8	Electrical field connections for downflow chilled water models FH599C/FH600C and FH739C/FH740C.	13
Figure 9	High voltage electrical field connections for upflow (UH) chilled water models except UH599C, UH600C, UH739C and UH740C	14
Figure 10	High voltage electrical field connections for upflow (UH) chilled water models for UH599C, UH600C, UH739C and UH740C (120" frame)	15
Figure 11	Low voltage electrical field connections for upflow (UH) chilled water models except UH599C, UH600C, UH739C and UH740C	16
Figure 12	Low voltage electrical field connections for upflow (UH) UH599C, UH600C, UH739C and UH740C (120" frame) chilled water models	17
Figure 13	Ducting configurations	19
Figure 14	Plenum dimensional data (FH/UH-147C—529C)	20
Figure 15	Plenum dimensional data (FH/UH-599C—740C)	21
Figure 16	Chilled water upflow general arrangement.	22
Figure 17	Chilled water downflow general arrangement	23
Figure 18	Downflow chilled water (FH) piping connections	24
Figure 19	Upflow chilled water (UH) piping connections except 599C, 600C, 739C and 740C	25
Figure 20	Downflow chilled water (599C, 600C, 739C and 740C) piping connections	26
Figure 21	Upflow chilled water (599C, 600C, 739C and 740C) piping connections	27

TABLES

Table 1	Model number designation	1
Table 2	Unit weights	1
Table 3	Downflow chilled water (except FH599C/FH600C and FH739C/FH740C) floor cutout dimensions.	5
Table 4	Downflow chilled water models FH599C/FH600C and FH739C/FH740C floor cutout dimensions.	6
Table 5	Upflow chilled water (UH models) cabinet and floor planning dimensional data	7
Table 6	Blower duct and deck dimensional data (UH 599C, 600C, 739C and 740C chilled water models.	9
Table 7	Recommended free area ft ² (m ²⁾ for grilles or perforated panels at output velocities of 550 and 600 fpm (2.8 and 3.1 m/s) 1	.8
Table 8	Plenum dimensional data in. (mm) for FH/UH-147C—529C	20
Table 9	Plenum dimensional data in. (mm) for FH/UH-599C—740C 2	21
Table 10	Downflow chilled water cooled (FH) piping connection sizes, inches	4
Table 11	Upflow chilled water cooled (UH) piping connection sizes, inches	5
Table 12	Downflow chilled water cooled (FH, 120" frame) piping connection sizes, inches 2	6

PRODUCT MODEL INFORMATION

Table 1	Model number designation
---------	--------------------------

		_					
DH FH	376	376 C		Α	Α	E	I
FH = Downflow CW	Nominal Capacity in Thousand	C = Chilled Water	- = Std. CW	A = 460/3/60 B = 575/3/60	A = Advanced Micro-processor	0 = No Reheat	0 = No Humidifier
UH = Upflow CW	BTU/H		V VSD = (Variabl	C = 208/3/60	G = Advanced Graphics	E = Electric Reheat	I = Infrared Humidifier
			e Speed	D = 230/3/60	Micro-processor		
			Drive)	F = 380/3/50		H Hot = Water	G Steam = Grid
				G = 415/3/50		Reheat	Humidifier
				H = 230/3/50		T = Steam	S = Steam
				J = 200/3/50		Reheat	Generatin g Humidifier
				M 380/415/ = 3/50			



WARNING

Installation and service of this equipment should be done only by qualified personnel who have been specially trained in the installation of air conditioning equipment. Improper installation could result in property damage, injury or loss of life.



WARNING

Hazardous voltage! Always disconnect power before servicing.



CAUTION

Evaporator unit requires drain connections and may also require water supply. Do not locate directly above any equipment that could sustain water damage.

EQUIPMENT INSPECTION

Upon arrival of the unit, inspect all items for either visible or concealed damage. Damage should be immediately reported to the carrier and a damage claim filed with a copy sent to Liebert or to your sales representative.

Table 2 Unit weights

	Model	Weight Ibs (kg)
Chilled Water Models	147C	770 (350)
FH/UH, 60 (50) Hz	200C	805 (365)
	248C	855 (388)
	302C	1090 (495)
	376C	1155 (524)
	422C	1320 (599)
	529C	1420 (644)
	600C (599C)	1785 (810)
	740C (739C)	1925 (873)

1.0 INTRODUCTION

1.1 System Descriptions

Deluxe System/3 12 to 60 ton Chilled Water environmental control system is available in several configurations. Each configuration can operate with either Advanced Microprocessor Controls (AM), or Advanced Microprocessor Controls with Graphics (AG). A brief description of each, including operational differences, can be found below. Check model numbers to see what is supplied with your unit.

1.1.1 Chilled Water Systems

Cooling

These systems utilize a central chiller and control cooling by modulating a control valve in the chilled water line.

Heating

Three stages of electric reheat standard; steam/hot water optional

Humidification

Infrared standard; steam grid and steam generating optional

Dehumidification

Chilled water valve opens proportionally in response to room needs

2.0 INSTALLATION

2.1 Room Preparation

The room should be well-insulated and must have a sealed vapor barrier. The vapor barrier in the ceiling can be a polyethylene film type. Use a rubber-base or plastic-base paint on concrete walls and floors. Doors should not be undercut or have grilles in them.

Outside, or fresh, air should be kept to an absolute minimum. Outside air adds to the heating, cooling, humidifying and dehumidifying loads of the site. It is recommended that outside air be kept below 5% of the total air circulated in the room.

2.2 Location Considerations

For a downflow unit, the unit can sit on an accessible, elevated flooring system. It may be necessary to furnish additional pedestal support below the unit to ensure maximum structural support. A separate floor stand for the unit may be used as support, independent of the elevated floor and installed prior to the flooring system.

For downflow and upflow units, provide approximately 34" (864 mm) service clearance on the left, right and in front of the unit whenever possible. The minimum space required for service is 18" (45.7 cm) on the left end, 18" (45.7 cm) on the right end, and 24" (61 cm) in front of the unit. This space is necessary to permit routine maintenance, such as replacing filters, adjusting the fan speed and cleaning the humidifier. On downflow chilled water units and upflow 599C, 600C, 735C and 740C models, left- and right-end minimum clearances are 0" (0 cm), with the exception of rear return.

\mathbf{c}


NOTE

If high efficiency 6" filters are used, 25" (63.5 cm) clearance on the right end is required for removal and replacement of filters.

Avoid locating units in an alcove or at the extreme end of a room that has a high aspect ratio (long narrow room). Also avoid locating units too close together. This tends to reduce the effectiveness of the air distribution as compared to units located 30-40 feet (9-12m) apart.

2.3 Unit Dimensions





Chilled		Dimensional Data inches (mm)												
Water Model	А	в	С	D	E	F	G	н	J	к				
FH147C	50 (1270)	46 (1168)	35 (889)	32 (813)	48 (1219)	33 (838)	10-1/2 (267)	35-1/2 (902)	35-5/8 (905)	31 (787)				
FH200C	50 (1270)	46 (1168)	35 (889)	32 (813)	48 (1219)	33 (838)	10-1/2 (267)	35-1/2 (902)	35-5/8 (905)	31 (787)				
FH248C	50 (1270)	46 (1168)	35 (889)	32 (813)	48 (1219)	33 (838)	10-1/2 (267)	35-1/2 (902)	35-5/8 (905)	31 (787)				
FH302C	74 (1880)	70 (1778)	35 (889)	32 (813)	72 (1829)	33 (838)	10-1/2 (267)	59-1/2 (1511)	35-5/8 (905)	31 (787)				
FH376C	74 (1880)	70 (1778)	35 (889)	32 (813)	72 (1829)	33 (838)	10-1/2 (267)	59-1/2 (1511)	35-5/8 (905)	31 (787)				
FH422C	99 (2515)	95 (2413)	35 (889)	32 (813)	97 (2464)	33 (838)	16-1/4 (413)	78-3/4 (2000)	35-5/8 (905)	31 (787)				
FH529C	99 (2515)	95 (2413)	35 (889)	32 (813)	97 (2464)	33 (838)	16-1/4 (413)	78-3/4 (2000)	35-5/8 (905)	31 (787)				

Table 3 Downflow chilled water (except FH599C/FH600C and FH739C/FH740C) floor cutout dimensions






Figure 2 Downflow chilled water models FH599C/FH600C and FH739C/FH740C cabinet and floor planning dimensional data


*NOTE: ELECTRICAL OPENING IS ALSO USED FOR DRAIN CONNECTION OF OPTIONAL STEAM GENERATING CANISTER HUMIDIFIER.

SL-18740pg7A

Chilled Water	Dimensional Data inches (mm)										
Model	Α	В	С	D	E	F	G	н	I		
FH599C, 600C	122	118	35	31	120	33	35-5/8	30	34		
	(3099)	(2997)	(889)	(787)	(3048)	(838)	(905)	(762)	(864)		
FH739C, 740C	122	118	35	31	120	33	35-5/8	30	34		
	(3099)	(2997)	(889)	(787)	(3048)	(838)	(905)	(762)	(864)		







Chilled			Dimensional Data inches (mm)											
Water Model	# of Blowers	Α	В	С	D	Е	F	G	н	J	к	L	М	
UH147C	1	50 (1270)	48 (1219)	46 (1168)	44 (1118)	3 (76)	5 (127)	18 (457)	15 7/8 (403)	18 5/8 (473)	2 3/16 (55)	17 3/8 (454)	-	
UH200C	1	50 (1270)	48 (1219)	46 (1168)	44 (1118)	3 (76)	5 (127)	18 (457)	15 7/8 (403)	18 5/8 (473)	2 3/16 (55)	17 3/8 (454)	-	
UH248C	1	50 (1270)	48 (1219)	46 (1168)	44 (1118)	3 (76)	5 (127)	18 (457)	15 7/8 (403)	18 5/8 (473)	2 3/16 (55)	17 3/8 (454)	-	
UH302C	2	74 (1880)	72 (1829)	70 (1778)	68 (1727)	3 (76)	4 (102)	20 (508)	15 7/8 (403)	14 5/8 (371)	2 3/16 (55)	20 3/8 (517)	11-1/4 (286)	
UH376C	2	74 (1880)	72 (1829)	70 (1778)	68 (1727)	3 (76)	4 (102)	20 (508)	15 7/8 (403)	14 5/8 (371)	2 3/16 (55)	20 3/8 (517)	11-1/4 (286)	
UH422C	2	99 (2515)	97 (2464)	95 (2413)	68 (1727)	6 1/2 (165)	5 (127)	18 (457)	15 7/8 (403)	18 5/8 (473)	3 1/4 (82)	20 5/8 (524)	12-5/8 (321)	
UH529C	2	99 (2515)	97 (2464)	95 (2413)	68 (1727)	6 1/2 (165)	5 (127)	18 (457)	15 7/8 (403)	18 5/8 (473)	3 1/4 (82)	20 5/8 (524)	12-5/8 (321)	




Figure 4 Cabinet and floor planning dimensional data (UH 599C, 600C, 739C and 740C chilled water models)

Figure 5 Blower duct and deck dimensional data (UH 599C, 600C, 739C and 740C chilled water models)




Table 6	Blower duct and deck dimensional data (UH 599C, 600C, 739C and 740C chilled water models
---------	--

				Dimensional Data inches (mm)						
Model	Blower	Supply	Motor Hp	Α	В	С	D	E	F	
	15x15	Top Front	10-15	27-1/2 (699)	3-1/2 (89)	18-11/16 (475)	16-3/16 (411)	10 (254)	4-1/2 (114)	
UH599C UH739C		Top Rear	10-15	27-1/2 (699)	12-5/16 (313)	18-11/16 (475)	16-3/16 (411)	10 (254)	4-1/2 (114)	
UH600C	15x11	Top Front	10-15	30	3-1/2	14-3/4	16-3/16	10	4-1/2	
UH740C		•	20	(762)	(89)	(375)	(411)	(254)	(114)	
		Top Rear	10-20	30 (762)	12-5/16 (313)	14-3/4 (375)	16-3/16 (411)	10 (254)	4-1/2 (114)	

2.4 Piping

All fluid and refrigeration connections to the unit, with the exceptions of the condensate drain and live steam, are sweat copper. Factory-installed piping brackets must not be removed. Field-installed piping must be installed in accordance with local codes and must be properly assembled, supported, isolated and insulated. Avoid piping runs through noise-sensitive areas, such as office walls and conference rooms.

Refer to specific text and detailed diagrams in this manual for other unit-specific piping requirements.

2.4.1 Drain Line

A 3/4" NPT (1-1/4" NPT on 599C, 600C, 739C and 740C) is provided for the evaporator coil condensate drain. This drain line also drains the humidifier, if applicable. The drain line must be located so it will not be exposed to freezing temperatures. The drain should be at least the full size of the drain connection and pitched a minimum of 1/8" per ft. (11 mm per meter).

NOTE

This line may contain boiling water. Use copper or other suitable material for the drain line.

For units without a condensate pump

The unit is shipped from the factory with an internally-mounted trap. No external trap is required. The drain line must comply with all applicable codes.

For units with a factory-installed condensate pump option

The unit is shipped from the factory with a condensate pump installed. The condensate pump discharge (drain) line must comply with all applicable codes.

For units with a field-installed condensate pump

The unit is shipped from the factory with the condensate pump option, unmounted in the unit, which must be installed in the field. The unit has an internally mounted trap. The drain line from the unit to the condensate pump does not require a trap. The discharge (drain) line from the pump must comply with all applicable codes.

2.4.2 Piping Considerations for Raised-Floor Applications

All piping below the elevated floor must be located so that it offers the least resistance to air flow. Careful planning of the piping layout under the raised floor is required to prevent the air flow from being blocked. When installing piping on the subfloor, it is recommended that the pipes be mounted in a horizontal plane rather than stacked one above the other. Whenever possible, the pipes should be run parallel to the air flow.

2.5 Electrical Connections

Three-phase electrical service is required for all models in either 208, 230, 460 or 575 V, 60 Hz; or 200, 230 or 400 V, 50 Hz. Electrical service shall conform to national and local electrical codes.

Install a manual electrical disconnect switch within 5 feet (1.6 m) of the unit in accordance with codes. A factory-supplied disconnect switch may be factory-mounted within the unit and accessible from the exterior.







Figure 7 Electrical field connections for downflow chilled water models (except FH599C/FH600C and FH739C/FH740C)



NOTE: Refer to specification sheet for full load amp. and wire size amp. ratings.

SL-18740pg11




Figure 8 Electrical field connections for downflow chilled water models FH599C/FH600C and FH739C/ FH740C

13

Figure 9 High voltage electrical field connections for upflow (UH) chilled water models except UH599C, UH600C, UH739C and UH740C





Figure 10 High voltage electrical field connections for upflow (UH) chilled water models for UH599C, UH600C, UH739C and UH740C (120" frame)








Figure 11 Low voltage electrical field connections for upflow (UH) chilled water models except UH599C, UH600C, UH739C and UH740C

SL-18740pg12A

(24 + 51), (24 +55), and (24 + 56).





NOTE: Refer to specification sheet for full load ampand wire size amp ratings.

SL-18740pg13A

2.6 Air Distribution Considerations

2.6.1 Raised-Floor Air Flow Distribution Considerations

To ensure proper air distribution, any unusual restrictions within the air circuit must be avoided. For under-floor air distribution, observe the following guidelines:

Select the air supply grilles and perforated panels for the raised floor to ensure minimum loss of pressure in the circuit. Air volume dampers on grilles, which extend several inches below the surface of the raised floor, are usually detrimental to airflow. Consideration of the height of the damper on the grille in conjunction with the floor height will determine whether this type of grille may be used.

The grilles used in raised floors vary in size, the largest being approximately 18" x 6" ($457 \times 152 \text{ mm}$). A larger grille size would be detrimental to the structural capacity of the raised floor panel. An 18" x 6" ($457 \times 152 \text{ mm}$) heavy-duty pencil proof type grille typically has 56 square inches (0.036 m^2) of free area. Perforated panels are available from various manufacturers of raised floors. These panels are usually 2' x 2' ($610 \times 610 \text{ mm}$) square and have a nominal free area of approximately 108 to 144 square inches ($0.07 \text{ to } 0.09 \text{ m}^2$). Use caution in selecting perforated panels as some manufacturers have only 36 to 40 square inches ($0.023 \text{ to } 0.026 \text{ m}^2$) of free area, requiring four times as many panels.

Avoid floor elevations below 7-1/2" (190.5 mm), loosely installed flooring systems, and below-floor obstructions such as: electrical wiring chases, unusually long computer system cables, or piping clusters.

All piping below the elevated floor must be located so that it offers the least resistance to air flow. Careful planning of the piping layout under the raised floor is required to prevent the air flow from being blocked. When installing piping on the subfloor, it is recommended that the pipes be mounted in a horizontal plane rather than stacked one above the other. Whenever possible, the pipes should be run parallel to the air flow.

Always check specifications of the floor supplier before specifying the total number of perforated panels and grilles required to handle the air flow. The proper specifications for grilles and perforated panels should indicate the total free area required for air delivery rather than the number of panels and grilles. (See **Table 7** below for recommended free area required for each model.) This table indicates the recommended free area based on having the supply air grilles and perforated panels sized to handle approximately 75% of the total cubic feet per minute (CFM) of the units at a velocity of 550 to 600 ft./min. (2.8 - 3.1 m/s). The remaining 25 percent of the air flow in the raised floor passes through cable cutouts, cracks between the panels and other leakage areas.

	-	•	•	
	Model FH 60 (50) Hz	550 fpm (2.8 m/s)	600 fpm (3.1 m/s)	
	147C	7.2 (0.65)	6.6 (0.60)	
	200C	8.2 (0.74)	7.6 (0.70)	
	248C	8.0 (0.73)	7.4 (0.67)	
Chilled	302C	12.7 (1.15)	11.6 (1.05)	
Water Units	376C	12.4 (1.13)	11.4 (1.03)	
	422C	17.0 (1.54)	15.6 (1.42)	
	529C	16.9 (1.53)	15.5 (1.41)	
	600C (599C)	23.3 (2.16)	21.4 (1.95)	
	740C (739C)	22.5 (2.09)	20.6 (1.89)	

Table 7Recommended free area ft² (m²) for grilles or perforated panels at output velocities of
550 and 600 fpm (2.8 and 3.1 m/s)


2.6.2 Upflow Systems Installation Considerations

Upflow models can be configured in several different ways with front return, rear return, or bottom return and top front supply or top rear supply. For in-room applications with no ductwork, and optional plenum with grill, proper clearance must be maintained on the return air side of the unit. For a front return, this means several feet in front of the unit. For a bottom return, at least 6-8 inches of unrestricted under-floor height is needed.

2.6.3 Ducted Application Installation

Duct flanges are supplied on the blower outlets. Follow the SMACNA-Duct Construction Standard for single-, dual-, or triple-blower systems. Do not run ductwork off the perimeter flange on the top of the unit. This flange is for positioning and attaching the optional air discharge plenum with grill. Attaching a duct to this flange may reduce airflow to inadequate levels.

Figure 13 Ducting configurations



* Follow standard practices on all duct work

2.6.4 Plenum Installation

When installing the plenum to the top of system, secure the plenum to the unit flange using sheet metal screws.


Q

NOTE

Air distribution plenums are available as Top Return/Downflow, Top Discharge/Upflow, and Front Discharge (with or without grilles)/Upflow. These plenums are shipped separate and unassembled. Refer to assembly manual included with plenums.

2.6.5 Filter Box Installation (Upflow Rear Return)

When installing the filter box to the back of the unit, secure the box to the unit using self tapping sheet metal screws. Seal around all edges with a silicone sealant to prevent air leakage.






Table 8	Plenum dimensional data in. (mm) for FH/UH-147C—529C
---------	--

Model	Α	В	С	D	E	F	Grille Free Area Sq Ft (sq m)
FH/UH-147C, 200C, 248C	50 (1270)	34 (864)	46 (1168)	32 (813)	44 (1118)	3 (76)	4.29 (.40)
FH/UH-302C, 376C	74 (1880)	34 (864)	70 (1778)	32 (813)	60 (1524)	7 (178)	5.85 (.54)
FH/UH-422C, 529C	99 (2515)	34 (864)	95 (2413)	32 (813)	70 (1778)	14-1/2 (368)	6.83 (.63)




Table 9Plenum dimensional data in. (mm) for FH/UH-599C—740C

Model	A	в	С	D	E	F	G	Н	J	Grille Free Area Sq Ft (sq m)
FH/UH-599C, 600C	122	34	118	32	44	3-1/2	4	7	16	10.14
FH/UH-739C, 740C	(3099)	(864)	(2997)	(813)	(1118)	(89)	(102)	(178)	(406)	(.94)

3.0 CHILLED WATER MODELS

3.1 Piping Considerations

Manual shut-off valves should be installed at the supply and return lines to each unit. This provides for routine service and emergency isolation of the unit.

The lowest water temperature to be supplied by the chiller will determine whether insulation is needed to prevent condensation on the supply and return lines. To prevent water damage to flooring and subflooring, install a water detection system, such as a Liqui-tect or floor drains with wet traps.

Figure 16 Chilled water upflow general arrangement







Figure 17 Chilled water downflow general arrangement







SL-18740pg9

Chilled Water Models	A (OD Cu)	B (OD Cu)	C (NPT Male)	D (OD Cu)	E (NPT Male)	F (OD Cu)
FH147C	1-1/8	1-1/8	1/2	5/8	1/2	5/8
FH200C	1-3/8	1-3/8	1/2	5/8	1/2	5/8
FH248C	1-5/8	1-5/8	1/2	5/8	1/2	5/8
FH302C	1-5/8	1-5/8	1/2	7/8	1/2	7/8
FH376C	2-1/8	2-1/8	3/4	7/8	3/4	7/8
FH422C	2-1/8	2-1/8	3/4	7/8	3/4	7/8
FH529C	2-1/8	2-1/8	3/4	7/8	3/4	7/8

Table 10Downflow chilled water cooled (FH) piping connection sizes, inches


Figure 19 Upflow chilled water (UH) piping connections except 599C, 600C, 739C and 740C

UNIT FIELD PIPING LOCATIONS

Piping stubbed out inside unit end compartment for field connection through 2 5/8" x 10 3/4" (66 x 273mm) opening as shown. Piping may also exit through bottom or top of end compartment by field cutting an opening in a suitable location (except bottom return air units).

PLENUM FIELD PIPING LOCATIONS

For seperate steam or hot water plenum in UPFLOW (UH) units, piping may exit through bottom, top or sides by field cutting an opening in a suitable location.



Chilled Water Models 50 & 60 Hz	A (OD Cu)	B (OD Cu)	C (NPT Male)	D (OD Cu)	E (NPT Male)	F (OD Cu)
UH147C	1-1/8	1-1/8	1/2	5/8	1/2	5/8
UH200C	1-3/8	1-3/8	1/2	5/8	1/2	5/8
UH248C	1-5/8	1-5/8	1/2	5/8	1/2	5/8
UH302C	2-5/8	2-5/8	3/4	7/8	1/2	7/8
UH376C	2-1/8	2-1/8	3/4	7/8	3/4	7/8
UH422C	2-1/8	2-1/8	3/4	7/8	3/4	7/8
UH529C	2-1/8	2-1/8	3/4	7/8	3/4	7/8





Table 12	Downflow chilled water cooled (FH	, 120" frame) piping connection sizes, inches
		,

120" Frame Chilled Water	A (OD CU)	B (OD CU)	C (NPT Male)	D (OD CU)	E (NPT Male)	F (OD CU)
FH599C, 600C	2-1/8	2-1/8	3/4	7/8	3/4	7/8
FH739C, 740C	2-5/8	2-5/8	3/4	7/8	3/4	7/8



Piping stubbed out inside unit end compartment for field connection through 13" x 6-1/2" (330 x 165mm) opening as shown. Piping may also exit through bottom of end compartment by field cutting an opening in a suitable location.



Ensuring The High Availability Of Mission-Critical Data And Applications.

Emerson Network Power, the global leader in enabling business-critical continuity, ensures network resiliency and adaptability through a family of technologies—including Liebert power and cooling technologies—that protect and support business-critical systems. Liebert solutions employ an adaptive architecture that responds to changes in criticality, density and capacity. Enterprises benefit from greater IT system availability, operational flexibility and reduced capital equipment and operating costs.

Technical Support / Service Web Site

www.liebert.com Monitoring 800-222-5877 monitoring@emersonnetworkpower.com Outside the US: 614-841-6755 Single-Phase UPS 800-222-5877 upstech@emersonnetworkpower.com Outside the US: 614-841-6755

Three-Phase UPS 800-543-2378 powertech@emersonnetworkpower.com **Environmental Systems**

> 800-543-2778 Outside the United States 614-888-0246

Locations

United States 1050 Dearborn Drive P.O. Box 29186 Columbus, OH 43229

Europe

Via Leonardo Da Vinci 8 Zona Industriale Tognana 35028 Piove Di Sacco (PD) Italy +39 049 9719 111 Fax: +39 049 5841 257 Asia

7/F, Dah Sing Financial Centre 108 Gloucester Road, Wanchai Hong Kong 852 2572220 Fax: 852 28029250

While every precaution has been taken to ensure the accuracy and completeness of this literature, Liebert Corporation assumes no responsibility and disclaims all liability for damages resulting from use of this information or for any errors or omissions.

© 2006 Liebert Corporation

All rights reserved throughout the world. Specifications subject to change without notice.

 R Liebert and the Liebert logo are registered trademarks of Liebert
 Corporation. All names referred to are trademarks or registered trademarks of their respective owners

SL-18205_REV1_08-06

Emerson Network Power.

The global leader in enabling Business-Critical Continuity[™].

Embedded Computing AC Power Systems

Connectivity

Embedded Power

DC Power Systems

Integrated Cabinet Solutions

Outside Plant Power Switching & Control Precision Cooling

EmersonNetworkPower.com Services Site Monitoring Surge Protection

Business-Critical Continuity, Emerson Network Power and the Emerson Network Power logo are trademarks and service marks of Emerson Electric Co ©2006 Emerson Electric Co.